



NP CHEMICAL PUMP

Part No.	Description	Part No.	Description
1-1	S/S Pump Body	1-1.18	Rod End 3/8"
1-2	Piston	1-1.18A	Rod end Bearing Nut
1-3	Foot	1-19	Connecting Rod
1-4	S/S Ball Check	1-20	Rod End 5/8"
1-5U	Upper Discharge Valve	1-20A	Rod end Bearing Nut
1-5L	Lower Discharge Valve	1-21	Clevis Pin 3/8"
1-6	Lower Discharge Valve Spring	1-22	Eccentric Bolt
1-7	Valve Gasket	1-22A	Eccentric Bolt Nut
1-8	Retaining Spring	1-23	Inside Eccentric Washer
1-9U	Upper Suction Valve	1-24	Outside Eccentric Dust Cap
1-9L	Lower Suction Valve	1-25	Eccentric
1-10	Reducer Hose	1-26	Measuring Dial
1-11	Packing	1-27	Pointer
1-12	Packing Spring Seat Collar	1-28	Motor Coupling
1-13	Packing Spring	1-29	Coupling Element
1-14	Packing Spring Cap Nut Gasket	1-30	Motor
1-15	Packing Spring Cap Nut	1-31	Gear Reducer
1-16	Alemite Fitting	1-32	Base Plate
1-17	Grease Lantern Ring	1-33	Reducer Support Spacer
		1-34	Pump Complete Set